

2. Prebacivanje parametara u sondu i logger

The image displays three sequential screenshots of the WinFluid software interface, illustrating the steps to switch parameters to the probe and logger.

Top Screenshot: The main window shows the 'Programming' tab. A callout box points to the 'Download' button with the text "Odaberi ikonicu sa satom". The 'Input channel' table is visible:

Input channel	Type
1 Hydrins II	Digital
2 Not programmed	Analogue

Middle Screenshot: The 'Process' tab is selected. A 'Program logger' dialog box is open, showing fields for 'Logger' (HydINS), 'Connection' (Local), and 'Port' (Com1). A callout box points to the dialog with the text "Otvorio se Program logger prozor". A warning message states: "Warning : all the logged data will be erased...".

Bottom Screenshot: The 'Program logger' dialog box is still open, and a callout box points to the 'Connect' button with the text "Odaberi Connect dugme".



